




396-4068Y1

2" Full Port Fill Kit for Two Tanks Installation Instructions

Kit Number: 520-00-102150

Kit Description: 2" Full Port Fill kit for Two Tanks



Shown with optional strainer.






Parts List and Step by Step Instructions

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	102-200VBR-90	2" Mounting Bracket - 90 Degree	2
2	102-200VBR	2" Mounting Bracket - Straight	1
3	102-220MVSCF	2" Manifold Stubby Valve Standard Port PolyValve	2
4	102-220MVSFFP	220 Series Manifold x 2" Male Quick Coupler Full Port Poly Valve	1
5	105-200G-H	2" EPDM Manifold Gasket for 220 Series Manifold Fittings	11
6	105-220BRB	2" Full Port Manifold x 2" HB	6
7	105-220MPT	2" Full Port Manifold x 2" MPT	2
8	105-220SWP90	2" Full Port 90° Sweep	2
9	105-220TEE	2" Full Port Flanged Tee	1
10	105-FC220	2" Full Port Manifold Clamp	11
11	106-200CAP	2" Cap	1
12	280-200-ENF	2" Enforcer Fertilizer Hose	40
13	333-0516	5/16" Fender Washer - 1" O.D.	6
14	341-120104	Self Drilling Screw - Size 12 x 1-1/4"	6
15	350-PS288	Pressure Seal HD Clamp (2" Enforcer)	9
16	384-1095	Hardware Kit - 3/8" Hex Cap Bolts and 3/8" Flange Nuts (Qty: 4)	1

Mounting Instructions:

1. Remove nuts on Poly Valve as required to fasten mounting brackets to valve and replace nuts, tighten. *(Often, only one bracket is used to mount the fill valve. Straight and 90° bracket are shown to illustrate both options.)*
2. Using hardware kits fasten poly valve mounting brackets to implement.
3. Continue to assemble fill connection assembly as shown.



4. Assemble 2" Manifold Tee assembly as shown.
6. Thread 2" Manifold x MPT fitting into tank opening.
7. Assemble tank valve manifold fittings as shown.
8. Route 2" hose from manifold tee assembly hose barb to each tank opening hose barb and tighten using hose clamps.